



Coloured covering is approx 5mm larger all round than the model.  
Use spare tissue to cover the top and bottom of the fuselage.

