

Hard 3mm square. Round forward edges.

Flying

Wind clockwise - launch with right bank
Wind anticlockwise - launch with left bank
Flies right/left or left/right

3mm gussets.

Wing

3mm square keel.

Balance

Wing

Cover with Jap tissue or mylar
Apply loose. Do not shrink or dope.

Frame

Wood is balsa unless stated.

3 x 6mm pylon.

Use wire insulation
on this end as a stop.

19 SWG (1mm) hinge pin.

0.4mm ply.
Cement one each side.

Bind & cement.

3mm gusset.

3 x 6mm motor stick.

4 strands 3mm sport rubber.

Bind & cement.

19 SWG (1mm) piano
wire crank/motor hook.

19 SWG (1mm) piano
wire motor peg.

asher

2mm brass tube bearing.

Conrod bent from soft wire (paperclip).
Wind pigtail at big end (2 turns).